



- 10 TON Capacity
- Designed for an AASHTO H20-44 Loading
- Complies with the 2004 MTO "Guidelines for the Design of Snowmobile Bridges"
- Exceeds Snowmobile Bridge Design Criteria in the MNRF 1992 "Crown Land Access Roads Manual" (Section RA3-3)
- Ideal for snowmobiles, trail groomers, ATV's and light traffic

INFORMATION GUIDE

4590 Regional Road 15, Chelmsford, ON POM 1L0 Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586 www.lessardwelding.com



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

What are these bridge superstructures designed and certified for?

Lessard's Recreational Bridges are designed and certified for an **AASHTO H20-44 Loading.** The bridges are used in instances where only light traffic is permitted (ATV's, Motorcycles, Snowmobiles, Groomers, light Cars, and Half Ton trucks.

Can Lessard bridge superstructures be used for temporary and/or permanent applications?

Our superstructures comply with the design requirements of the 2004 MTO "Guidelines for the Design of Snowmobile Bridges" AND exceed the snowmobile bridge design standards identified in the Ministry of Natural Resources and Forestry 1992 "Crown Land Access Roads Manual" (Section RA3-3). Our recreational bridges can be used for both temporary and permanent crossings and are designed for ease of installation and use on trails adjacent to low volume roads.

What do I need to know about the bridge substructure (abutments/cribbing)?

Our recreational bridges require 12" (300 mm) of continuous support under the bridge at each end of the bridge. We recommend that clients use the services of a Professional Engineer to investigate site conditions and carryout detailed design (including substructures) for all bridge installations.

Lessard Welding offers custom fit solutions to fit the Lessard Portable Bridges between **existing abutments**, however, the existing abutment must be inspected by a Professional Engineer and approved for installation. Exact measurements are required and must be submitted at the time of order

How does the Lessard Bridge Superstructure's design make life easier?

a) SAFE AND DURABLE DESIGN

The Lessard Bridge Superstructures are professionally designed with safety in mind. Our heavy-duty design consists of 2 separate sections; each having three girders for a total of six girders per bridge



superstructure. The inside of the girders is reinforced with diaphragms that provide lateral support to steel stringer beams during loading. Bridge decking consists of a 3/8" (10 mm) thick steel checker plate that is supported across all steel stringers by structural channels. The reinforcing prevents checker plate deformation and distributes vehicle loads across each steel stringer. All structural steel used in Lessard Welding bridges is certified to be NEW.



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

b) SIZE AVAILABILITY AND LOW PROFILE

We offer multiple bridge lengths - each with a low structure profile which makes them easier to transport, handle and install. Each section measures 6' wide. Once installed, the bridge offers a total running surface width of 12'.

Our modular bridge products are available in standard lengths (as per the table below) and custom lengths up to 60 ft.

Superstructure	20 ft.	30 ft.	40 ft.	50 ft.	60 ft.
Height	16"	16"	20"	25"	28"
Actual Length (tip to tip)	20'-61/2"	30'- 8"	40'- 7 1/4"	50'-81/4"	60'- 9"

c) TAPERED OR SQUARE ENDS

Our bridges are manufactured with either a tapered or square end at no additional cost.



Tapered end bridges are excellent for use in locations where the bridge is installed on a substructure that does not have an upper approach crib leading to the deck. In these instances gravel can be tapered up onto the structure - preventing the bridge ends from being exposed which could be damaged during snow grooming operations or damage snowmobile skis if left exposed.



Square

Tapered Ends

Square end bridges are best suited for use on permanent installations at sites with existing wooden cribs with decks where an exact elevation match is required.

d) STEEL CHECKER PLATE DECKING

Lessard Bridge Superstructures are shipped complete with a 3/8" pre-welded steel checker plate deck. Compared to a timber deck, a steel deck offers significant savings in maintenance (labor and wood) over the lifecycle of the bridge.

e) HIGH PERFORMANCE COATING AND ANTI-SLIP SURFACE

To ensure proper adhesion of paint and non-slip coatings, all main stringer beams are cleaned and shot blasted in accordance with SSPC-SP 6 industry standard. We also apply a high-performance red oxide primer to the entire structure including underneath the bridge. In addition, as part of the painting process, a dense grit product is added that helps prevent workers from slipping and falling during construction and provides additional tire traction after installation.





Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

f) DECKING



Our modular bridge decking is designed to ensure a level and uniform surface between bridge sections. With proper substructure planning, traffic moves smoothly across the structure. Impact loading caused by uneven surfaces can significantly reduce the lifespan of bridge stringers. An even surface will also minimize or eliminate damage caused by

grooming. Since the sections are fabricated with precision, the gap in between the two sections is very small (+- 1/8'') and will reduce or eliminate road materials from entering the water body below or collecting on lower flanges of the center beams.



g) DECKING ACCESS POINTS AND WEIGHTED COVER PLATES

There are access points or "cut outs" in the surface of the decking to allow installers to bolt the two sections together. Weighted Cover Plates are provided to ensure all openings are well covered and that the deck surface remains level and flush. We recommend using high strength construction adhesive to secure the cover plates. Cover plates and cutouts are uniform in size and are interchangeable.







h) PULLING LUGS



There are (3) Pulling Lugs pre-welded to each end of each section for a total of (12). These lugs are reinforced to provide safe lifting and pulling locations for easy bridge installation.



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

i) LIFTING LUGS

There are (4) recessed Lifting Lugs welded within the deck surface. We also provide (4) Load Rated Lifting Slings for your convenience. These lifting locations are ideal for loading, offloading and bridge installation. Cover caps are provided to cover the lifting lug openings for a safe walking surface.



The Tie Downs are used to align and connect each bridge sections together. The Tie Down Guides are small pieces of angle iron welded to the top of the Tie Downs of section #1 (as shown in photo) to ensure quick and easy alignment of section #2. When aligning both sections together, we recommend using a larger steel pull/crow bar to align the holes perfectly and to keep hands away from the connection while moving bridges. Once all Tie Downs are aligned, simply insert a bolt into the hole.

k) NUT LOCKING BARS

Once the bolts are inserted into the holes of the tie downs, simply position the nut underneath the tie down and carefully hold it in between the two Nut Locking Bars. You are now able to torque the bolt into place from the top of the deck.

I) STRUCTURAL GRADE BOLTS

These are included with every bridge. Light oil or a product like "Never Seize" should be applied to the bolts during installation to ensure long term maintenance.











	0.161	9	12)100100		
	6 ft.	25"	16,800 lbs		
	6 ft.	28"	22,350 lbs		
N	w.lessardwelding	.com	Page 6 of 11		

Height

16"

16"

20"

Bridge Specifications

Bridge Span

20 ft.

30 ft.

40 ft. 50 ft.

60 ft.

One bridge consists of two (2) sections. Please find specifications of each section for each standard bridge available.

Dimensions and Weight per Section

Width

6 ft.

6 ft.

6 ft



Actual Length

(from tip to tip)

20' 6 1/2"

30' 8"

40' 7 1/4"

50' 8 1/4"

60' 9"



n) EASY TO INSTALL OR REMOVE

Installation of a Lessard Portable Bridge is simple. Each bridge section is clearly identified as either "Section 1" or "Section 2". Bridge sections are typically delivered to the site one on top of each other with guard rail

WELDED POST POCKETS m)

Our guide rail pockets consist of 6" x 6" x 12" deep hollow structural steel tubing pre-welded at every 6' 3" (as required) to the outer sides of the bridge. The pockets are spaced in accordance with OPSD requirements for posts for curbs, pedestrian handrail or guiderail (if required).

RECREATIONAL BRIDGES Modular Type

Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586





Weight

5,100 lbs

8,725 lbs

12 150 lbs





Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

o) PRE-ASSEMBLED IN SHOP

As part of the fabrication process and quality control, our modular bridges are shop assembled before shipping to ensure each section is an exact match and that assembly in the field is hassle free.

p) PRE-DRILLED ANCHOR HOLES

Each bridge section has pre-drilled anchor holes at each corner of the end beams. One end has round (fixed) holes and one end has slotted holes that allow for the expansion and contraction of the bridge superstructure caused by heat and cold temperatures. All four corners are to be fastened to the abutment. Anchor bolts are NOT provided as it depends on the engineered abutment design required.



q) UNIQUE IDENTIFICATION NUMBER

Every Lessard Modular bridge has its own unique identification number for easy record keeping purposes. During fabrication, an identification plate is welded to the outside stringers of each bridge section. The ID plate provides a unique identification number as well as the identifying each bridge section. We maintain an up to date database for all fabricated bridges and can provide owners and customers of fabrication dates, original purchaser, date of purchase and other related information.

r) INTERNAL QUALITY CONTROL INSPECTION

In accordance with our high-quality control standards, every bridge fabricated by Lessard Welding is thoroughly inspected to ensure completeness and adequacy of fabrication in accordance with the sealed drawings.

s) BRIDGE DOCUMENTATION

Customers receive bridge documentation for each individual bridge.

1. Sealed General Arrangement Drawing

All customers receive sealed general arrangement drawings that provides basic measurements and assembly information for the product purchased.

2. Certificate of Conformance

All customers receive a certificate of conformance for their specific bridge. An engineer performs a certified inspection to ensure completeness and adequacy of fabrication in accordance with the detailed drawing as designed and approved by the bridge designer.



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

Does Lessard offer technical support?

Unlike the competition, we provide a wide range of technical support to each our valued customers. Our staff have over 40 years of practical construction experience as well as expert knowledge of all regulatory requirements of the Ministry of Natural Resources and Forestry, the Occupational Health and Safety Act and the Department of Fisheries and Oceans. Our customers can take advantage of the complementary and premium technical services described below.

Mr. Tim Lee's Contact Information

Email: tim@lessardwelding.com

Cell: 705-644-3976

a) COMPLIMENTARY SERVICES – Free of charge

Our customers receive technical advice from our expert support staff related to the following:

- Logistics involved with bridge installations, road construction and maintenance
- Bridge superstructure span selection and hydrology advice
- MNRF/DFO approvals process
- Assistance in assembling complete application packages required to obtain approvals thereby speeding up the review time by the various agencies involved

b) PREMIUM SERVICES – Details available upon request

In addition to the services identified above, Lessard Welding is now able to offer the following premium services to our valued customers on a fee for service basis:

- Field training related to visual inspections of bridges and inventory management
- Road maintenance and construction training
- Engineering and project management services

What do I need to know about a Bridge Re-certification?

We value all customers – both present and past. There may be instances where the MNRF requires a Lessard Recreational Bridge (that has been used at multiple locations in the past) to be recertified by a Professional Engineer before it can be re-used.

These instances could include the following:

- If the bridge was damaged during the installation or removal process
- If the bridge was fabricated prior to 1995

As part of our ongoing commitment to our customers, we can provide contact information for Professional Engineers in your geographic location who are familiar with our products and can perform the re-certification for a nominal fee. Please contact our office by email or phone for more information.



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

Does Lessard Welding offer Bridge Rehabilitation services?

We are pleased to inform you that we offer low-cost bridge rehabilitation services in our facility for bridges that have minor damage or defects. These services may include minor repairs, deck and exterior cleaning or sandblasting (if required), repainting as well as bridge re-certification for installation by a Professional Engineer. For a free estimate, mail or email photos of your bridge to steve@lessardwelding.com

What are the upgrades or options available to purchase with the bridges?

All the following upgrades or options come at an extra cost, we would be more than happy to provide you with a cost estimate upon your request.

a) ON-SITE SUPPORT

Customers may request the assistance of our bridge expert on the day of installation. This would be to ensure compliance with design criteria. Insurance limitations prevent physical labor by onsite technical staff.

b) BRIDGE DELIVERY

Shipping costs are NOT included in the price of our bridges, but delivery is available for an additional cost. Special MTO permits may be required depending on the bridge dimensions.

If you are PICKING UP your bridge...

- You will need to inform us ahead of time of the date and time you plan on picking up your bridge as we may need to make special lifting arrangements to load the bridges.
- Flatbed trailers are the preferred type of trailer for us to load your bridges. If you don't plan on using a flatbed trailer, we will likely encounter loading challenges and therefore you must communicate with us prior to the shipping date to discuss your plan, otherwise you may risk the possibility of NOT getting loaded at all or having to wait for a crane to come on site which could lead to a loading charge of approximately 1000\$.
- Uneven deck type trailers such as goose necks are acceptable but must be equipped with blocks to level off the loaded bridge.
- Logging trailers with pickets are acceptable, however, please note, that pickets will need to be removed by the driver on the one side. Please note that you may not be able to put the pickets back into place afterwards due to where the bridge pockets line up on the trailer.
- Please know that it is possible to ship more than one bridge on one truck depending on the quantity and spans ordered.

If WE ARE SHIPPING your bridge...

- You will need to inform us ahead of time of the date and time delivery is required.
- You will need to send us by email a site address, map or driving instructions as well as a site contact.
- Please know that it is possible to ship more than one bridge on one truck depending on the quantity and spans ordered.



Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

What are the maintenance requirements?

Simple maintenance can dramatically extend the lifespan of a Lessard Portable Bridge. Recommended maintenance activities include the following:

- Routine visual inspections to confirm that the bridge is fully supported at each end by a level and sound substructure.
- Removing gravel buildup on the steel deck and bearing seats. Gravel by itself is abrasive to painted surfaces and in larger volumes can retain water that will accelerate surface rust.
- Store portable bridges horizontally and elevate them on blocks. The blocking will ensure that the bridge stringers do not come in direct contact with standing water.
- Use only the lifting locations identified to move a portable bridge. Lifting at other locations may damage flanges, decking and guard rail pockets.
- Power wash bridges in storage to remove accumulated soil materials.
- Store smaller bridge parts (bolts, washers, nuts and plates) in an interior location.
- Greasing or oiling all bolts, washers and nuts is advisable.
- Periodic sandblasting and painting of bridges in storage is also advisable.
- Maintain a bridge file with original bridge drawings and update with maintenance records.

What is the design life of this type of bridge?

Lessard's Recreational Bridges are designed for a 40 year service life, however poor site design, installation, mishandling, overloading and lack of maintenance may impact it's service life. As well, re-coating of the bridge and/or touch-ups may be required during its service life due to normal wear and tear, excessive use by track based equipment, vehicles with chains, corrosive environments and frequency of flood (overtopping) events. Good record keeping, annual inspections, minor maintenance (removal of loose gravel from deck, replacing signage, repair of curbs or barriers) are all recommended.

What kind of experience does Lessard Welding have?

Established in 1974, Lessard Welding has **over 40 years of experience,** the expertise and the resources to deliver a wide range of high quality welding products - including bridges. There are over 600 Lessard Bridges currently in service in North America. We also provide custom welding services and products to the mining industry.

We are family owned and operated with a reputation that matches our experience. We also offer bilingual services - from ordering products to continued technical support.



RECREATIONAL BRIDGES

Modular Type

Tel: 705-855-3480 Toll Free: 888-234-3687 Fax: 705-855-5586

What certifications does Lessard Welding have?

Premier Fabrication Standards and Quality Control are built into every Lessard Portable Bridge Superstructure. Lessard Welding is certified to CSA Standard W47.1 in Division 2 by the Canadian Welding Bureau and maintains a superior Quality Management System which complies with the requirements of the ISO 9001:2015 standards.



Contact Information

If you have any other questions, please feel free to communicate with us at any time!

Bridge Sales and Technical Questions – Tim Lee

Cell: 705-644-3976 Email: <u>tim@lessardwelding.com</u>

General Manager - Steve Lessard

 Address:
 4590 Regional Road 15, Chelmsford, ON POM 1L0

 Tel:
 705-855-3480

 Toll Free:
 888-234-3687

 Fax:
 705-855-5586

 Email:
 steve@lessardwelding.com